

Audi VEHICLE DIAGNOSTIC REPORT

Vehicle Information

--/Audi/Audi A4/S4/RS4 USA/CAN 2009>/--
VIN: WAUZZZ8K8DA111853Odometer Reading: 217350km
License Plate: CD57MPGP

Customer Information



















Name: MFC Dekra Nedbank Auction House

Tel: 0861033572

Device information

Scanner: MaxiSys MS906 BT
Version: V19.50Serial Number: VB8GJCC01509
Repair Order Number: --

System Scanned(21)

System	Status/DTC
01 - Engine Control Module 1	 45
02 - Transmission electronics	 1
03 - Brakes 1	 3
05 - Access/start authorization	 2
08 - Air Conditioning	 9
09 - Electronic central electric	 4
15 - Airbag	 1
16 - Steering column electronics	 2
17 - Instrument cluster	 3
19 - Gateway	 3
2E - Media Player Position 3	 0
42 - Driver's door electronics	 1
44 - Power Steering	 3
46 - Comfort System Central Control Module	 4
47 - Sound system	 2
52 - Passenger's door electronics	 1
53 - Parking Brake	 2
56 - Radio	 0

62 - Left rear door electronics	 1
72 - Right rear door electronics	 1
77 - Telephone	 2

**DTC (90)****01 - Engine Control Module 1 (45 DTCs)**

DTC	Description	Status
P268100	Engine Coolant Bypass Valve Control Circuit/Open	Active/static
P218400	Coolant temperature sensor 2 circuit low	Passive/Sporadic
P218500	Coolant temperature sensor 2 circuit high	Passive/Sporadic
P130A00	Cylinder suppression	Passive/Sporadic
P21D100	Cylinder 3 injector B Circuit/open	Active/static
P007000	Ambient Air Temperature Sensor Circuit	Active/static
P305400	Starter does not turn Mechanically blocked or electrical malfunction	Passive/Sporadic
P253300	Ignition Switch Run/ Start Position Curciut	Passive/Sporadic
P008900	Fuel Pressure Regulator 'A' Performance	Passive/Sporadic
P119A00	Fuel pressure sensor Malfunction	Active/static
P008700	Fuel rail/system pressure - too low	Passive/Sporadic
P00B700	Engine Coolant Flow Low/Performance	Passive/Sporadic
P00B700	Engine Coolant Flow Low/Performance	Active/static
P030000	Random/multiple cylinder Misfire detected	Passive/Sporadic
P125000	Fuel level too low	Active/static
P030100	Cylinder 1 Misfire detected	Passive/Sporadic
P030300	Cylinder 3 Misfire detected	Passive/Sporadic
P030400	Cylinder 4 Misfire detected	Passive/Sporadic
P030200	Cylinder 2 Misfire detected	Passive/Sporadic
P001600	Crankshaft Position (CKP)-Camshaft Position (CMP) Correlation (bank 1 sensor A)	Passive/Sporadic

P001100	A Camshaft Position (Bank1) Timing over-advanced or System Performance	Active/static
P001400	B Camshaft Position (Bank1) Timing over-advanced or System Performance	Passive/Sporadic
P003000	O2 Sensor Heater Contr. Circ.(Bank1(1)Sensor 1)	Active/static
P223700	O2 Sensor Positive Current Control Circuit Bank 1 Sensor 1 Open	Active/static
P219500	O2 Sensor Signal Stuck Lean Bank 1 Sensor 1	Active/static
P219600	O2 Sensor Signal Stuck Rich Bank 1 Sensor 1	Passive/Sporadic
P013500	O2 Sensor Heater Circ.,Bank1-Sensor1 Malfunction	Passive/Sporadic
P013600	O2 Sensor Circ.,Bank1-Sensor2 Malfunction	Active/static
P011300	Intake air temperature sensor 1 (bank 1) Circuit high	Passive/Sporadic
P227900	Intake air system leakage	Passive/Sporadic
P006800	MAP/MAF - Throttle Position Correlation	Passive/Sporadic
P010800	Manifold absolute pressure/barometric pressure High input	Passive/Sporadic
P023800	Turbocharger boost sensor (A) circuit High input	Passive/Sporadic
P017100	Fuel Trim,Bank1 System too Lean	Active/static
P000A00	A Camshaft Position (CMP) slow response (bank 1)	Passive/Sporadic
U015100	Lost Communication With Restraints Control Module	Passive/Sporadic
U021200	Lost communication with steering column control unit	Passive/Sporadic
U012800	Lost communication with brake system control unit	Passive/Sporadic
U013100	Lost communication with power steering control unit	Passive/Sporadic
U010100	Lost Communication with TCM	Passive/Sporadic
U015500	Lost communication with instrument cluster control unit	Passive/Sporadic
U012600	Lost Communication With Steering Angle Sensor Module	Passive/Sporadic
U012100	Lost Communication With Anti-Lock Brake System (ABS) Control Module	Passive/Sporadic
U014000	Lost Communication With Body Control Module	Passive/Sporadic
U042300	Invalid data received from Instrument cluster control unit	Active/static

02 - Transmission electronics (1 DTC)

DTC	Description	Status
P178F00	Pressure control valve soiled	Passive/Sporadic

03 - Brakes 1 (3 DTCs)

DTC	Description	Status
01317:013	Instrument cluster control module - Please read DTC	Active/static
00446:002	Function limitation due to insufficient voltage - Lower limit not reached	Passive/Sporadic
00473:013	Electronic parking brake control module -J540- - Please read DTC	Passive/Sporadic

05 - Access/start authorization (2 DTCs)

DTC	Description	Status
01330:013	Comfort system central control module - Please read DTC	Active/static
00446:002	Function limitation due to insufficient voltage - Lower limit not reached	Passive/Sporadic

08 - Air Conditioning (9 DTCs)

DTC	Description	Status
00457:013	Vehicle Electrical System Control Module - Please read DTC	Active/static
00256:002	Sensor for refrigerant pressure/temperature - Lower limit not reached	Active/static
01317:008	Instrument cluster control module - Implausible signal	Active/static
01274:002	Oil Pressure Actuator - Lower limit not reached	Passive/Sporadic
01274:001	Oil Pressure Actuator - Upper limit exceeded	Passive/Sporadic
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic
00446:000	Function limitation due to insufficient voltage	Passive/Sporadic
03269:000	Function limitation due to energy management	Active/static
02095:000	Component protection active	Passive/Sporadic

09 - Electronic central electric (4 DTCs)

DTC	Description	Status
02988:000	Left-/right hand driving switch-over active	Active/static
00779:012	Outside temperature sensor - Electrical error in circuit	Active/static
00446:002	Function limitation due to insufficient voltage - Lower limit not reached	Passive/Sporadic
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic

15 - Airbag (1 DTC)

DTC	Description	Status
U101100	Supply voltage Voltage too low	Passive/Sporadic

16 - Steering column electronics (2 DTCs)

DTC	Description	Status
00446:002	Function limitation due to insufficient voltage - Lower limit not reached	Passive/Sporadic
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic

17 - Instrument cluster (3 DTCs)

DTC	Description	Status
00457:013	Vehicle Electrical System Control Module - Please read DTC	Active/static
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic
02095:000	Component protection active	Passive/Sporadic

19 - Gateway (3 DTCs)

DTC	Description	Status
03041:000	Energy management active	Passive/Sporadic
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic
03708:002	Voltage stabilizer stage 1 supply voltage - Lower limit not reached	Passive/Sporadic

42 - Driver's door electronics (1 DTC)

DTC	Description	Status
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic

44 - Power Steering (3 DTCs)

DTC	Description	Status
U140000	Function restriction Caused by low voltage	Passive/Sporadic
U140100	Function restriction Caused by excessive voltage	Passive/Sporadic
U140A00	Terminal 30 Open circuit	Passive/Sporadic

46 - Comfort System Central Control Module (4 DTCs)

DTC	Description	Status
01317:013	Instrument cluster control module - Please read DTC	Active/static
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic

01512:002	Control Module For Sunroof - Lower limit not reached	Passive/Sporadic
03156:002	Anti-theft alarm system sensor - Lower limit not reached	Passive/Sporadic

47 - Sound system (2 DTCs)

DTC	Description	Status
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic
02095:000	Component protection active	Passive/Sporadic

52 - Passenger's door electronics (1 DTC)

DTC	Description	Status
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic

53 - Parking Brake (2 DTCs)

DTC	Description	Status
U101100	Supply voltage Voltage too low	Passive/Sporadic
U111300	Function limitation due to received malfunction value	Active/static

62 - Left rear door electronics (1 DTC)

DTC	Description	Status
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic

72 - Right rear door electronics (1 DTC)

DTC	Description	Status
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic

77 - Telephone (2 DTCs)

DTC	Description	Status
00532:002	Supply voltage - Lower limit not reached	Passive/Sporadic
00446:002	Function limitation due to insufficient voltage - Lower limit not reached	Passive/Sporadic

Technician Notes

2016335030

Customer name: _____

Technician: _____

Date: _____

Note: Please save a copy of this report for your records.